Recommended to Add a SBL-1 Silicone

Box Liner (#10) or a foil liner (Sold Separately) into the Lower Bucket for cleanliness prior to grilling.



THE GREASE BOX PATENT NUMBER 11812895

For Recteq SmokeBox Accessory (Single Drain)



Cleanup & Maintenance:

It's recommended to empty grease contents after every use. <u>Use care when</u> <u>opening or emptying The Grease Box as contents or the product may be HOT.</u> We recommend using gloves when cleaning The Grease Box. After removing contents, rinse out with soap and warm water then hand dry only.





THE GREASE BOX LLC

Questions, comments or missing parts? Contact us > support@thegreasebox.com Register your products within 30 days of purchase for warranty.

WARNING: ATTACHING THIS PRODUCT MAY VOID THE WARRANTY TO YOUR OUTDOOR COOKING APPARATUS. THE GREASE BOX LLC IS NOT LIABLE FOR FAULTY INSTALLATIONS, IMPROPER MAINTENANCE, ANY DAMAGES OR ISSUES RESULTING FROM THE USE OF THE GREASE BOX ON THE COOKING APPARATUS.



WARNING: This product can expose you to chemicals including lead, which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information, go to www.p65warnings.ca.gov.

STEP 1: Confirm the fit

- Visit: **thegreasebox.com/compatibility** to check the fit This installation manual is for the Recteq SmokeBox accessory for a single drain on new Recteq models (with an undermount grease spout).
- Make sure grill is turned off & cooled.
- Remove grease bucket (Image **A**). Clean the bottom of the SmokeBox area. Remove the inner racks & grease tray within the SmokeBox prior to install.

STEP 2: (Use Image B)

Add Lock to Mounting Bracket (#1) in following order: Shoulder Screw (#4), Lock (#5) then High-Heat Plastic Washer (#3). Use screwdriver to install. Synch tighter to slow Lock swivel.



STEP 3: (Use Image C)

Hold the Mounting Bracket (#1) up against the bottom of the SmokeBox accessory. Center the grease spout within the opening of the Mounting Bracket (#1).

STEP 4: (Use Image C)

Use a marker or pencil to mark the holes of the outer x4 Weld Nuts (#6) onto the bottom surface of the SmokeBox. Place Mounting Bracket aside.

Note: Grease Tray and racks inside should be removed prior to drilling.

Use a 1/4" metal drill bit to pilot out the marked holes from below.

Drilling may void Manufacturer's Warranty. Install at your own risk.















STEP 5: (Use Image D & E)

Place Screws (#2) & Washers (#7) from inside the SmokeBox down through the four drilled holes.

Hold up Mounting Bracket (#1), and line up each Screw (#2) into the Weld Nuts (#6) at all 4 corners below.

With your other hand, advance each screw evenly until bracket is secure and does not move.

FINAL STEP: (Use Image F)

Rotate lock (#5) upwards.

***Recommended:** add a SBL-1 Silicone Box Liner or foil liner into the Lower Bucket for cleanliness prior to grilling. Flip to Back Page for Info and Care & Use.

Slide lower bucket into drawer rails. Push it all the way back and rotate Lock (#5) down.

The Grease Box is fully installed, locked, and ready for its first cook